



**BESTDECK**  
• COMPOSITE WOOD •

Composite Wood Decking, Wall Cladding, Fluted  
Panelling, Pergola, Balustrade, Gates and SPC Flooring

[www.bestdeck.co.za](http://www.bestdeck.co.za) | WhatsApp 064 864 7823 | Tel: 010 500 2897 | [info@bestdeck.co.za](mailto:info@bestdeck.co.za)  
Building 8, Riversands Outlet Park, Riversands Boulevard, Midrand

## CARE FOR AND CLEAN YOUR DECKING

# THE DOs AND DONTs FROM BEST DECK

Clean decking is easy to achieve and makes the world of difference to the overall look and feel of your home or building. Here are some tips to ensure that your composite wood products look great and last longer.

### DOs

- Use a hard-bristled broom (or scrubbing brush) with water and Sunlight® soap to clean your Gold Range composite wood products. Regarding the Diamond Range please use a medium bristle brush. Scrub your decking vigorously at least once a week to keep it looking new.
- For stubborn debris or a very thorough clean, add Cleen Green® to your Sunlight® and water mixture and use this to clean the deck. Cleen Green® is available at most hardware stores and can be used on a regular basis, or when there is a problem area that needs special attention.
- Spar or apply undiluted Cleen Green® to an especially stubborn stain and scrub it with a cloth or fine steel wool. Steel wool should only be used on the Gold Range Grooved Planks and not on the Best Deck Diamond Range Wood Grain Plank.
- Although the Diamond Range planks can be cleaned like the other ranges, scuffs and scratches should be treated differently. If the outer skin of the Best Deck Diamond Range Wood Grain Plank is damaged (within reason), heat the damaged area with a heat gun or hair dryer. The outer skin can shrink in the heat, covering over minor damage.

### DONTs

- Do not use a mop on the Gold Range Groove Decking, as it just moves the dirt around instead of removing it. Eventually the decking will look worn and filthy. Rather follow the suggestions above for achieving clean decking.
- Never apply methylated spirits (or straight alcohol) to any of Best Deck's composite wood products. It will damage the material. Follow the suggestions under the "Dos" section above to remove stubborn stains and scuff marks from your composite wood products.
- When using a high-pressure hose to clean decking and other composite wood products, only use soft to medium pressure. The highest pressure will damage the planks.
- Even at the right pressure, do not use figure-8 motions when cleaning the decking with a high-pressure hose.
- Do not put heavy items on your composite wood deck planks without some kind of protection. Dragging something heavy across the decking will scratch and damage the planks, possibly even irreparably. For heavy plants or furniture, be sure to have a rubber mat of between four and six millimetres thick between the object and the deck. For heavy umbrellas, consider adding large castor wheels to make moving them around easier and safer for your decking. Small wheels will make grooves in the deck too.

If you have any questions, would like more tips to care for and clean decking, or to order your beautiful composite wood products today, contact Best Deck today.